
## **<u>10- Pin Video Connections.</u>**



On JVC equipment (& its Badged versions) the pin layout is ...

- 1. VIDEO in & out (Higher DC voltage on play > Camera)
- 2. Gnd
- 3. batt alarm/rec ind
- 4. Gnd
- 5. Audio Playback
- 6. Start/Stop
- 7. Audio in
- 8. Gnd
- 9. Gnd
- 10. +12V (1A?)

The information contained upon this page is supplied in good faith, and to the best of my knowledge is accurate. However, I accept no responsibility for damage or injury, however caused, due to the use of this data. It was originally posted to the Packet radio System by John G8MNY in JAN 2001